

LifeinaBox

*For the optimum storage
of fragile medication*

THE FREEDOM TO TRAVEL

Designed for the safe storage of fragile medication at an optimum temperature (2 - 8°C). Keeps your medication cool and at a constant temperature at work, at home or in your car.

CONSTANT TEMPERATURE

Refrigerates up to 8 standard injectable medicine pens or vials*. Includes both a universal 110-240V power cord and a 12V DC power adapter for your car.

BETTER CONTROL

The Lifeina app will monitor the temperature of your medication in real time and will send you automatic reminders when it is time for you to take your medication.

BUILT-IN BATTERY

A 6-hour battery is included inside LifeinaBox, and separate plug-in battery packs are available.

RECOMMENDED USES

Insulin, growth hormones, adrenalin, monoclonal antibodies, vaccines, interferons*

www.lifeina.com.au

*For a comprehensive list of compatible pens and medications, log-on to www.lifeina.com.au



"It's time to start living the life you've imagined"

Henry James

- ▶ *Compact and portable*
- ▶ *Connected to the Lifeina app for real-time monitoring of temperature*
- ▶ *Automatic medication reminders*
- ▶ *Low-noise fan for quiet operation*
- ▶ *Built-in battery*
- ▶ *Useable in car (12V) or home (110-240V)*

Did you know? The LifeinaBox mini-refrigerator uses thermoelectric technology. Thermoelectrics convert thermal energy into electrical energy to produce cold.

Thermoelectric refrigeration uses a principle called the "PELTIER" effect to pump heat electronically. The Peltier effect is named after Jean Charles Athanase Peltier, a French scientist who discovered it in 1834.

Live your life



COMPACT DESIGN

CONNECTED

TRACK TEMPERATURES

6-HOUR BATTERY

USEABLE ANYWHERE

Specifications

Dimensions:	220 x 107 x 110mm
Cavity size:	180mm wide x 65mm deep x 40mm high (468cm ²)
Capacity:	8 prefilled insulin pens
Net Weight:	1350gm
Voltage:	12V DC auto socket cord or 110-240V AC domestic power cord, UL approved
Battery	2 x 3.7V Li-ion 5200mAh
Average power consumption:	25 watts max
Temperature range:	2°C to 8°C, +/- 1°C.
Insulation:	CFC-free polyurethane foam
System:	Wear-free thermoelectric technology with interior semiconductor fan
Material:	ABS and brushed aluminum
Reference:	LifeinaBox

Specifications are subject to technical improvement, changes or modifications without notice




Lifeina SAS
6 Rue de Castellane
75008 Paris, France
hello@lifeina.com
www.lifeina.com.au